



PRODUCT GUIDE- HYDROWAX

Application:

Hydrowax should be applied with a sponge, rag or spatula/wide putty knife in thin, even coats over an entire surface. It should be allowed to dry 5-10 minutes before being buffed to a high sheen using a clean rag or mechanical buffer. As Hydrowax may become too thin to apply properly in warm weather, it may be chilled for a short time for more optimal application. Hydrowax is ready to use, touch dry in 1 to 3 hours, and tools should be cleaned with warm, soapy water.

Coverage:

250-500 sq. ft. per 1-quart container