



## PRODUCT GUIDE- STUCCO LAMUNDO

### Preparation:

- Surface should be smooth, clean and dust free.
- New surface – Prime substrate with PVA acrylic primer and let it dry fully. Apply one coat of Meoded Quartz Primer™ allowing it 3-5 hours to dry.
- Existing surface – Any surface with sheen should be sanded, then prime the surface with multi-purpose primer and let it dry fully. Next apply one coat of Meoded Quartz Primer™ allowing it to dry for 3-5 hours.
- Preparation of flat surfaces requires only the application of Meoded Quartz Primer™.

### Application Methods:

Use stainless steel trowel or spatula to apply the three coats of Stucco Lamundo™.

First coat – First coat of Stucco Lamundo™ should be applied thinly and evenly, covering the entire wall. Allow at least 12 hours for the base coat to dry.

Second coat – If it's necessary to smooth, slightly sand the first coat with 180-320 grit sandpaper before proceeding. The second coat should be applied and spread tightly in an overlapping patches pattern. Allow second coat to dry for at least 5-7 hours.

Third coat & Burnishing – Apply this finish coat in the same manner as second coat.

When the surface material is still moist start burnishing by gradually pressing and smoothing the material . The more you burnish the shinier and glossier the surface will become.

### Sealer:

After allowing a minimum of 48 hours to dry, it is recommended that you apply a protective coat of HydroWax™ to provide your finish with protection from moisture and dirt while also enhancing sheen and gloss.

### Coverage:

20 kg 350-450 sq. ft. for three coats, depending on surface and texture.